

## BLC Box (30058)



### Installation



#### **Danger!**

Installation work may only be carried out by qualified persons who have been assigned to carry out this work.



#### **Caution!**

Use only original Industri-  
elektronik Pözl GmbH spare parts.

If you use third-party spare parts there is no guarantee that they have been designed optimized for application or for safety.

### Operation



#### **Caution!**

Only use the battery charging and compensating box at ambient temperatures between -40 °C and +85 °C.

### Dismantling



#### **Danger of short circuit!**

Detach the three wires on the battery.

### Service



#### **Danger!**

Servicing work must only be carried out by qualified people who have been tasked with this work.



#### **Danger!**

Only the manufacturer or a qualified service engineer are allowed to carry out repairs on the battery charging and compensating box.

**Central**

Industrieelektronik Pözl GmbH  
Großendorf 122  
4551 Ried im Traunkreis, Austria

Tel.: +43 (0)7588 – 70 122  
Fax: +43 (0)7588 – 70 125  
E-mail: [office@poelz.at](mailto:office@poelz.at)  
Web: [www.poelz.at](http://www.poelz.at)

**office** Germany

IEP Pözl GmbH  
Laufener Straße 59  
83395 Freilassing, Germany

Tel.: +49 (0)8654 – 478 670  
Fax: +49 (0)8654 – 478 673  
E-mail: [office@poelz.at](mailto:office@poelz.at)  
Web: [www.poelz.at](http://www.poelz.at)